

WASTN

Low floor scales

stationary



The high-quality electronic scales is characterised by particularly practical handling. With an access height of only 2 cm these scales can be placed in the aisles and do not need to be embedded into the floor, thus saving expenses! The installation of smart and innovative details allows fast and easy weighing of animal groups, comfortable for humans and animals.

In brief:

- Access height only 2 cm
- Remote unlocking of exit doors by foot pedal as standard (entrance gate optionally)
- High-quality dust-protected and water jet-proof weighing technology. Can be cleaned with high-pressure cleaner
- Cables protected against rodents
- 3 years warranty
- USB port with saving option!

Standard dimensions

W x L

1.10 m x 2.10 m
1.10 m x 2.50 m
1.10 m x 3.10 m
1.10 m x 3.50 m
1.10 m x 4.10 m
1.10 m x 4.50 m
1.10 m x 5.10 m
1.40 m x 2.50 m
1.40 m x 3.10 m
1.40 m x 3.50 m
1.40 m x 4.10 m
1.40 m x 4.50 m
1.40 m x 5.10 m
1.80 m x 3.10 m
1.80 m x 3.50 m
1.80 m x 4.10 m
1.80 m x 4.50 m
1.80 m x 5.10 m

Other dimensions on request



*Even for a 5 kg piglet
a small step*

WASTN

Performance

in detail

Animals step on a specially developed corrugated scales base that combines anti-skid properties with easy cleaning. The cross corrugation ensures good accessibility, lengthwise corrugation ensures good cleaning.

The specially for these scales developed floor profile with low dead weight and low access height allows retrofitting into any aisle.

The cables of 4 stainless steel weighing bars are installed inside the rails to be protected against rodents.

- Animal weighing program for moving animals
- Intuitive 4-color sorting
- Automatic re-taring
- Power supply by adapter or optionally battery operation
- Calibration on request



- Extremely low ramp height of just 2 cm - easy access for people and animals
- The 2-way gates can be opened both outwards and inwards. This allows the weighing equipment to be used right up against the pen gate.
- Narrow rod spacing in the gates - for weighing piglets as well.



SIMPLY INGENUOUS

Transport mechanism

The scales can be moved to the gangway using the transport mechanism. This enables the full gangway width to be used - with the liquid manure grate and plug fully accessible.

Foot pedal

Remote control using the foot pedal allows the exit gate to be opened from the entry side. The animals can be conveniently herded through.

